





SQUARE LINE

Frame not working//bordet virker ikke

PICTURE: BILLEDE:	PROBLEM: PROBLEM:	SOLUTION: LØSNING:
	Is the green light on in the transformer? Er der grønt lys i transformeren?	NO 1. Check 220V outlet and wire to transformer. 2. Unplug for 3 minutes, plug in again. 3. Still no green light? CHANGE THE TRANSFORMER
	YES JA	
	Connect the motor to the transformer – very briefly. (Remove quickly!) Was the frame moving? Forbind motor kortvarigt direkte med transformer. (Tag hurtigt fra igen!) Kørte bordet op?	NO CHANGE THE MOTOR LEG
	YES JA	
	Connect the wires again (red/red), according to the assembly instructions. Forbind ledningerne igen (rød/rød), iht. instrukser i samlevejledningen.	
	YES JA	
	Check if the buttons are used correctly. Does the frame work? Tjek om knapperne på betjeningspanelet fungerer korrekt. Kører bordet nu?	NO CHANGE CONTROL PANEL
	YES JA	NEJ UDSKIFT BETJENINGSPANEL

Congratulations! Your height adjustable frame is now working.

Tillykke! Dit hæve-/sænkebord virker.